

CR 208 P

Teileliste
Parts list



[joint system](#)[®]

via volvera 123

10090 bruino torino italy

t +39 011 957 29 54

f +39 011 908 42 94

p.iva / c.f. 07028380017

info@jointssystem.com

Pos.	Artikel-Nr. Part no	Makopak-Nr.	Benennung	Part name
1	1831.032.002		Getriebegehäuse komplett	Gear housing complete
2	1831.032.001		Lagerplatte	Bearing plate
3	1832.039.002		Deckel	Cover
4	1831.011.001		Grundplatte	Base plate
5	1831.011.002		Knickleiste, 0,8 - 1,0 mm	Knee piece, 0,8 - 1,0 mm
6	1821.080.001		Griff	Lever
7	1821.025.001		Mutter	Nut
8	1821.034.002		Welle	Shaft
9	1821.040.001		Spannrad	Tension wheel
10	1821.043.001		Spannmatrize	Tension plug
11	1821.034.001		Achse	Axe
12	1821.020.010		Distanzbüchse	Spacer bushing
13	1821.063.001		ZTA-Ritzel	ZTA-Pinion
14	1821.063.002		ZTA-Rad	ZTA-Wheel
20	1820.010.213		Druckfeder	Compression spring
21	1917.401.145		Distanzscheibe	Distance washer
22	1933.820.120		Nadelhülse	Needle bushing
23	1933.722.162		Nadelhülse	Needle bushing
24	1933.914.120		Nadelhülse	Needle bushing
25	1933.910.120		Nadelbüchse	Needle bushing
26	1934.330.151		Axiallager	Trust bearing
27	1934.310.350		Axiallager	Trust bearing
28	1921.304.120		Zylinderstift	Cylindric pin
29	1910.505.082		Gewindestift	Threaded pin
30	1911.006.168		Zylinderschraube	Cylinder screw
31	1911.005.149		Zylinderschraube	Cylinder screw
32	1911.005.108		Zylinderschraube	Cylinder screw
34	1921.305.160		Zylinderstift	Cylindric pin
36	1919.606.072		Sicherungsscheibe	Lock washer
37	1919.605.062		Sicherungsscheibe	Lock washer
40	1921.306.220		Zylinderstift	Cylindric pin
41	1912.908.006		Ringschraube	Ring screw
50	1894.425.000		Druckluftmotor, LZB 33 A 005-64	Compressed air motor, LZB 33 A 005-64

Pos.	Artikel-Nr. Part no	Benennung	Part name
51	1895. 312. 003	Scheibenfeder	Key
67	1820. 090. 068	Ölschild	Oil tag
68	1940. 311. 721	Stecknippel, G 1/4"	Air plug, G 1/4"
69	1821. 090. 003	Firmenschild	Name tag
70	181. 106. 036	Druckreguliertventil	Pressure control valve

		Ausführung USA/CAN	Variation USA/CAN
68	1820. 100. 019	Stecknippel, 1/4" NPT	Air plug, 1/4" NPT
71	1820. 100. 017	Übergangsnippel, R 1/4"-1/4" NPT	Transition connector, R 1/4" x 1/4" NPT

TEILELISTE DRUCKLUFTMOTOR

PART LIST COMPRESSED AIR MOTOR

Pos.	Artikel-Nr. Part no	Benennung	Part name
1	1894.425.002	Ventilgehäuse	Valve housing
2	1894.425.011	Getriebegehäuse (Rückseite)	Gear housing (Rear side)
3	1894.432.026	Schalldämpfer	Silencer
4	1894.432.027	Sieb	Mesh screen
5	1894.432.005	Kugellager	Ball bearing
6	1894.432.004	Lagerplatte hinten	Bearing plate rear
7	1894.432.006	Stift	Pin
8	1894.432.003	Zylinder	Cylinder
9	1894.422.001	Rotor	Rotor
10	1894.422.002	Lamelle	Blade
11	1894.432.002	Keil	Pin
12	1894.432.009	Lagerplatte vorn	Bearing plate front
13	1894.432.001	Kugellager	Ball bearing
14	1894.432.013	Scheibe	Disc
15	1894.432.021	Kugellager	Ball bearing
16	1894.332.015	Achse	Shaft
17	1894.332.016	Nadelkranz	Needle cage
18	1894.422.003	Planetenrad	Planetary wheel
19	1894.422.004	Planetenwelle	Planetary cage
20	1894.432.025	Gewindebüchse	Threaded bushing
21	1894.432.024	Tellerfeder	Saucer spring
22	1894.432.017	Achse	Shaft
23	1894.332.024	Lagernadel	Bearing needle
24	1894.432.016	Planetenrad	Planetary wheel
25	1894.432.018	Planetenwelle	Planetary cage
26	1894.432.023	Getriebegehäuse (Frontseite)	Gear housing (Front side)
27	1894.432.020	Dichtung	Gasket
28	1894.432.022	Frontstück	Front part
29	1894.324.005	Reduziernippel	Air connection
30	1894.425.005	O-Ring	O-Ring
31	1894.425.006	Distanzring	Spacer ring

