


CR25a

Teileliste Parts list



[joint system®](http://joint-system.com)

via volvera 123

10090 bruino torino italy

t +39 011 957 29 54

f +39 011 908 42 94

p.iva / c.f. 07028380017

info@joint-system.com

Pos.	Artikel-Nr. Part no	Benennung	Part name	
1	1174. 200. 115	Zylinder	Cylinder	
5	1174. 200. 114	Zylinderdeckel	Cylinder cover	
8	1820. 100. 036	Ventilstößel, lang	Valve stem, long	
9	1820. 100. 030	Hülse	Sleeve	
10	1820. 100. 033	Ring	Ring	
11	1820. 100. 034	Hülse	Sleeve	
12	1927. 601. 020	O-Ring	O-Ring	
13	1927. 601. 600	O-Ring	O-Ring	
14	1820. 010. 208	Druckfeder	Compression spring	
16	1820. 100. 035	Ventilstößel, kurz	Valve stem, short	
17	1820. 100. 031	Büchse	Sleeve	
18	1820. 100. 032	Büchse	Sleeve	
19	1925. 010. 802	Kugel	Ball	
20	1820. 010. 047	Druckfeder konisch	Compression spring conical	
21	1927. 600. 420	O-Ring	O-Ring	
23	1174. 200. 120	Kolben	Piston	
24	1928. 011. 050	Kolbenring	Piston ring	
25	1927. 600. 610	O-Ring	O-Ring	
26	1820. 020. 261	Scheibe	Washer	
27	1916. 306. 062	Sicherheitsmutter	Lock washer	
28	1927. 601. 010	O-Ring	O-Ring	
29	1174. 200. 137	Flachdichtung	Gasket	
32	1174. 200. 131	Schieber	Slider	
33	1820. 030. 413	Bolzen	Bolt	
34	1174. 200. 128	Lasche	Link	
36	1174. 200. 141	Zange 13 mm	Jaw	13 mm
36	1174. 200. 142	Zange 16 mm	Jaw	16 mm
36	1174. 200. 143	Zange 19 mm	Jaw	19 mm
38	1174. 200. 125	Kerbmesser 13 mm	Notcher	13 mm
38	1174. 200. 126	Kerbmesser 16 mm	Notcher	16 mm
38	1174. 200. 127	Kerbmesser 19 mm	Notcher	19 mm
40	1174. 200. 132	Platte	Plate	
41	1174. 200. 133	Frontplatte 13 mm	Front plate	13 mm
41	1174. 200. 134	Frontplatte 16 mm	Front plate	16 mm

Pos.	Artikel-Nr. Part no	Benennung	Part name
41	1174. 200. 135	Frontplatte 19 mm	Front plate 19 mm
44	1820. 020. 262	Büchse	Bushing
45	1820. 020. 263	Büchse	Bushing
46	1820. 030. 415	Bolzen	Bolt
47	1820. 030. 414	Bolzen	Bolt
48	1820. 030. 412	Spezierschraube	Special screw
49	1911. 905. 252	Senkschraube	Counter sunk screw
50	1916. 305. 052	Sicherheitsmutter	Lock nut
53	1174. 200. 124	Abschneidmesser komplett 16, 19 mm	Cutter complete 6, 19 mm
53	1174. 200. 152	Abschneidmesser komplett 13mm	Cutter complete 13 mm
57	1174. 200. 121	Messerführung	Cutter guide
58	1921. 305. 120	Zylinderstift	Straight pin
59	1820. 010. 207	Druckfeder	Compression spring
63	1174. 200. 148	Grundplatte komplett, inkl. Pos. 64-67 16 mm	Base plate complete, incl. pos. 64-67 16 mm
63	1174. 200. 149	Grundplatte komplett, inkl. Pos. 64-67 19 mm	Base plate complete, incl. pos. 64-67 19 mm
63	1174. 200. 150	Grundplatte komplett, inkl. Pos. 64-67 13 mm	Base plate complete, incl. pos. 64-67 13 mm
65	1921. 304. 080	Zylinderstift, 19mm	Straight pin
65	1921. 304. 100	Zylinderstift, 16mm	Straight pin
65	1921. 304. 120	Zylinderstift, 13mm	Straight pin
66	1174. 200. 145	Bandführung 19 mm	Strap guide 19 mm
66	1174. 200. 146	Bandführung 13 mm	Strap guide 13 mm
66	1174. 200. 147	Bandführung 16 mm	Strap guide 16 mm
67	1921. 902. 085	Schwerspannstift	Roll pin
70	1820. 040. 101	Spannmatrize	Tension plug
71	1910. 104. 088	Gewindestift	Set screw
73	1820. 030. 416	Spezierschraube	Special screw
74	1820. 030. 417	Spezierschraube	Special screw
77	1174. 200. 116	Getriebegehäuse inkl. Pos. 78	Gear housing complete
78	1935. 510. 100	Radial-Gleitlager	Slide bearing
82	1820. 030. 410	Achse	Axe
83	1820. 010. 209	Drehfeder	Torque spring
84	1921. 804. 122	Schwerspannstift	Roll pin
86	1933. 908. 080	Nadelbüchse	Needle bearing,
87	1933. 815. 120	Nadelhülse	Needle bushing

Pos.	Artikel-Nr. Part no	Benennung	Part name
88	1928. 615. 213	Dichtring	Gasket
89	1820. 030. 411	Spannwelle	Tension shaft
90	1173. 200. 063	Keil	Key
91	1820. 060. 082	Schnecke	Worm gear
92	1820. 060. 081	Schneckenrad	Worm gear wheel
93	1820. 040. 100	Spannrad	Tension wheel
96	1934. 310. 150	Axial-Nadellager	Thrust bearing
97	1934. 430. 150	Gegenscheibe	Counter washer
98	1934. 015. 120	Nadelbüchse	Needle bushing
101	1174. 200. 118	Deckel, links inkl. Pos. 78	Cover, left
104	1174. 200. 111	Deckel, rechts	Cover, right
107	1174. 200. 139	Taste, gelb	Lever, yellow
108	1174. 200. 140	Taste, grün	Lever, green
109	1174. 200. 138	Bolzen	Bolt
110	1820. 030. 418	Spezialschraube	Special screw
111	1820. 010. 211	Schenkelfeder	Torque spring
112	1820. 010. 210	Schenkelfeder	Torque spring
115	1174. 200. 117	Handgriff	Handle
121	1940. 070. 723	Drosselrückschlagventil	One-way restrictor, G 1/4"
128	1173. 400. 044	Schlauch	Air hose
129	1941. 210. 720	Dichtscheibe	Gasket
130	1941. 111. 040	Schlauchtülle	Hose connection
131	1941. 112. 720	L-Verschraubung	L-Connection
132	1940. 331. 188	Schlauchklemme	Hose clamp
136	1934. 310. 100	Axial-Nadellager	Thrust bearing
137	1934. 430. 100	Gegenscheibe	Counter washer
140	1174. 200. 157	Aufhängebügel	Suspension bow
141	1940. 311. 721	Stecknippel	Air plug, G 1/4"
147	1911. 005. 208	Zylinderschraube	Cylinder screw
148	1911. 005. 168	Zylinderschraube	Cylinder screw
149	1919. 605. 062	Sicherungsscheibe	Lock washer
150	1911. 005. 128	Zylinderschraube	Cylinder screw
151	1911. 005. 258	Zylinderschraube	Cylinder screw
153	1911. 272. 127	Verschlusschraube	Locking screw, G 1/4"

Pos.	Artikel-Nr. Part no	Benennung	Part name
155	1820.090.068	Ölschild	Oil lable
158	1894.332.000	Druckluftmotor LZB 22 A008-50	Air motor, Type LZB22 A008-50
159	1174.200.136	Scheibenfeder	Key
163	1174.200.162	Abdeckung	Cover
166	1820.090.198	Firmenschild	Name tag
167	1820.090.172	Schild "Made in Swizeriand"	Label "Made in Switzerland"
168	1174.200.155	Klinke	Handle
169	1820.010.010	Druckfeder	Compression spring
175	1174.200.154	Anschlusswinkel	Connection angle

TEILELISTE DRUCKLUFTMOTOR

PART LIST COMPRESSED AIR MOTOR

Pos.	Artikel-Nr. Part no	Benennung	Part name
1	1894. 332. 011	Endplatte	End plate
2	1894. 332. 010	Getriebegehäuse (Rückseite)	Gear housing (Rear side)
3	1894. 332. 013	Schalldämpfer	Silencer
4	1894. 332. 033	Sieb	Mesh screen
5	1894. 332. 002	Kugellager	Ball bearing
6	1894. 332. 003	Lagerplatte hinten	Bearing plate rear
7	1894. 332. 001	Stift	Pin
8	1894. 332. 005	Zylinder	Cylinder
9	1894. 332. 004	Rotor	Rotor
10	1894. 332. 007	Lamelle	Blade
12	1894. 332. 009	Lagerplatte vorn	Bearing plate front
13	1894. 332. 008	Kugellager	Ball bearing
15	1894. 332. 014	Kugellager	Ball bearing
16	1894. 332. 015	Achse	Shaft
17	1894. 332. 016	Nadelkranz	Needle cage
18	1894. 332. 017	Planetenrad	Planetary wheel
19	1894. 332. 019	Planetenwelle	Planetary cage
20	1894. 332. 020	Gewindebüchse	Threaded bushing
21	1894. 332. 021	Tellerfeder	Saucer spring
22	1894. 332. 022	Achse	Shaft
23	1894. 332. 024	Lagernadel	Bearing needle
24	1894. 332. 023	Planetenrad	Planetary wheel
25	1894. 332. 026	Planetenwelle	Planetary cage
26	1894. 332. 029	Getriebegehäuse (Frontseite)	Gear housing (Front side)
27	1894. 432. 020	Dichtung	Gasket
28	1894. 332. 028	Frontstück	Front part