

# CR26a

## Teileliste Parts list



joint system®

via volvera 123

10090 bruino torino italy

t +39 011 957 29 54

f +39 011 908 42 94

p.iva / c.f. 07028380017

[info@jointssystem.com](mailto:info@jointssystem.com)

<b>Pos.</b>	<b>Artikel-Nr. Part no</b>	<b>Benennung</b>	<b>Part name</b>
1	1831.011.003	Zylinder	Cylinder complete
6	1831.011.004	Sicherungsring	Retaining ring
7	1820.020.281	Scheibe	Washer
8	1831.011.005	Gehäuse komplett	Housing complete, incl. pos. 9-11
9	1935.510.100	Radial-Gleitlager	Slide bearing
10	1935.000.200	Innenring	Internal ring
11	1935.510.150	Radial-Gleitlager	Slide bearing
13	1831.032.003	Getriebegehäuse inkl. Pos. 14	Gear housing
14	1821.020.031	Büchse	Bushing
17	1832.039.002	Deckel	Cover
18	1174.400.051	Flansch	Flange
19	1174.400.067	Schalldämpfer	Silencer
20	1831.032.001	Lagerplatte	Bearing plate
23	1821.101.002	Kolben	Piston
24	1831.011.006	Grundplatte "E" 0.8mm , 32mm	Base plate "E" 0.8 mm 32 mm
24	1831.011.008	Grundplatte "E", 32mm	Base plate "E", 32 mm
24	1831.011.007	Grundplatte 25mm	Base plate 25 mm
24	1831.011.014	Grundplatte, 0.8 mm 25mm	Base plate, 0,8 mm 25 mm
26	1831.021.012	Platte vorn, 25mm	Plate front, 25 mm
26	1831.021.013	Platte vorn, 32mm	Plate front, 32 mm
27	1831.021.002	Platte hinten, 25mm	Plate rear, 25 mm
27	1831.021.004	Platte hinten, 32mm	Plate rear, 32 mm
28	1174.400.061	Schieber, 25mm	Slider
28	1831.021.005	Schieber, 32mm	Slider, 32 mm
29	1821.200.005	Zange, 25 mm (1")	Jaw 25mm
29	1821.200.004	Zange, 32mm	Jaw 32 mm
30	1821.200.002	Kerbmesser 25mm	Notcher 25 mm
30	1821.200.003	Kerbmesser 32mm	Notcher 32 mm
31	1174.400.065	Lasche, 25mm	Link
31	1821.205.003	Lasche, 32 mm (11/4")	Link 32mm
33	1934.450.060	Gegenscheibe	Counter washer
34	1820.030.444	Bolzen; 25mm	Bolt
34	1821.033.004	Bolzen, 32mm	Bolt
35	1821.033.008	Bolzen	Bolt

<b>Pos.</b>	<b>Artikel-Nr. Part no</b>	<b>Benennung</b>	<b>Part name</b>
36	1820.030.439	Bolzen	Bolt
37	1820.020.278	Büchse	Bushing
38	1916.306.062	Sicherheitsmutter	Lock nut
40	1821.208.002	Abschneidemesser, pos. 41 25 mm	Cutter, incl. pos. 41 25 mm
40	1821.208.011	Abschneidemesser, "A", inkl. pos. 41 25 mm	Cutter "A", incl. pos. 41 25 mm
40	1821.208.009	Abschneidemesser, "E", inkl. pos. 41 32 mm	Cutter "E", incl. pos. 41 32 mm
41	1921.602.081	Spiralstift	Spiral pin
43	1927.614.020	O-Ring	O-Ring
44	1927.601.410	O-Ring	O-Ring
45	1928.011.500	K-Ring	K-Ring
46	1820.020.277	Scheibe	Washer
48	1916.308.082	Sicherheitsmutter	Lock nut
51	1820.100.032	Büchse	Bushing
52	1820.010.047	Druckfeder konisch	Compression spring conical
53	1925.010.802	Kugel	Ball
54	1820.100.041	Ventilstößel kurz	Valve stem short
55	1927.601.600	O-Ring	O-Ring
56	1820.100.031	Büchse	Bushing
57	1927.600.420	O-Ring	O-Ring
61	1821.010.001	Druckfeder	Compression spring
62	1820.100.039	Ring	Ring
63	1820.100.042	Ventilstößel lang	Valve stem long
65	1927.600.820	O-Ring	O-Ring
66	1820.100.038	Hülse	Sleeve
67	1820.100.037	Hülse	Sleeve
69	1927.600.600	O-Ring	O-Ring
70	1927.601.710	O-Ring	O-Ring
72	1821.034.004	Achse	Shaft
73	1821.020.016	Büchse	Bushing
74	1820.040.098	Spannrad	Tension wheel
75	1917.401.145	Distanzscheibe	Spacer disk
76	1933.914.120	Nadelhülse	Needle bushing
77	1921.306.220	Zylinderstift	Straight pin
79	1821.070.001	O-Ring	O-Ring

<b>Pos.</b>	<b>Artikel-Nr. Part no</b>	<b>Benennung</b>	<b>Part name</b>
82	1933. 722. 162	Nadelhülse	Needle bearing
83	1934. 310. 350	Axiallager	Trust bearing
85	1821. 063. 002	ZTA-Rad	ZTA-Wheel
86	1821. 063. 001	ZTA-Ritzel	ZTA-Pinion
87	1831. 033. 001	Achse	Shaft
88	1926. 502. 200	Nadelhülse	Free wheel
89	1934. 330. 151	Axiallager	Trust bearing
94	1894. 422. 000	Druckluftmotor, LZB 33 A 005-63	Air motor, LZB 33 A 005-63
95	1895. 312. 003	Scheibenfeder	Woodruff key
101	1821. 039. 021	Bolzen	Bolt
102	1820. 020. 279	Büchse	Bushing
105	1820. 030. 442	Verschlusschraube	Locking screw
106	1925. 210. 042	Tellerfeder	Saucer spring
107	1820. 030. 441	Bolzen	Bolt
108	1925. 010. 702	Kugel	Ball
109	1820. 030. 443	Stiftschraube	Set screw
110	1174. 400. 069	Rolle	Roll
111	1174. 400. 068	Aufhängebügel	Suspension bow
114	1174. 400. 076	Hebel, grün	Lever green
115	1174. 400. 077	Hebel	Lever yellow
117	1174. 400. 078	Welle	Shaft
118	1920. 103. 062	Sicherungsscheibe	Lock washer
125	1174. 400. 079	Klinke	Pawl
128	1911. 305. 162	Zylinderschraube	Cylinder screw
129	1911. 005. 258	Zylinderschraube	Cylinder screw
130	1911. 005. 168	Zylinderschraube	Cylinder screw
131	1911. 005. 128	Zylinderschraube	Cylinder screw
132	1919. 605. 062	Sicherheitsmutter	Lock nut
133	1917. 803. 056	Scheibe	Washer
137	1820. 010. 144	Druckfeder	Compression spring
138	1933. 910. 120	Nadelbüchse	Needle bushing
140	1941. 112. 720	L-Verschraubung	L-Connection, G 1/4"
141	1941. 111. 040	Schlauchanschluss	Hose connection
142	1940. 070. 723	Drosselrückschlagventil	One-way restrictor, G 1/4"



## TEILELISTE DRUCKLUFTMOTOR

## PART LIST COMPRESSED AIR MOTOR

Pos.	Artikel-Nr. Part no	Benennung	Part name
1	1894.432.012	Endplatte	End plate
2	1894.432.011	Getriebegehäuse (Rückseite)	Gear housing ( Rear side)
3	1894.432.026	Schalldämpfer	Silencer
4	1894.432.027	Sieb	Mesh screen
5	1894.432.005	Kugellager	Ball bearing
6	1894.432.004	Lagerplatte hinten	Bearing plate rear
7	1894.432.006	Stift	Pin
8	1894.432.003	Zylinder	Cylinder
9	1894.422.001	Rotor	Rotor
10	1894.422.002	Lamelle	Blade
11	1894.432.002	Keil	Key
12	1894.432.009	Lagerplatte vorne	Bearing plate front
13	1894.432.001	Kugellager	Ball bearing
14	1894.432.013	Scheibe	Washer
15	1894.432.021	Kugellager	Ball bearing
16	1894.332.015	Achse	Shaft
17	1894.332.016	Nadelkranz	Needle cage
18	1894.422.003	Planetenrad	Planetary wheel
19	1894.422.004	Planetenwelle	Planetary shaft
20	1894.432.025	Gewindebüchse	Threaded bushing
21	1894.432.024	Tellerfeder	Saucer spring
22	1894.432.017	Achse	Shaft
23	1894.332.024	Lagernadel	Bearing needle
24	1894.432.016	Planetenrad	Planetary wheel
25	1894.432.018	Planetenwelle	Planetary shaft
26	1894.432.023	Getriebegehäuse (Frontseite)	Gear housing ( Front side)
27	1894.332.027	Dichtung	Gasket
28	1894.432.022	Frontstück	Front part