


OR4000.13

Teileliste
Parts list



[joint system](#)®

via volvera 123

10090 bruino torino italy

t +39 011 957 29 54

f +39 011 908 42 94

p.iva / c.f. 07028380017

info@jointssystem.com

Pos.	Artikel-Nr. Part no	Benennung	Part name
1	2973. 100. 093	Gehäuse komplett inkl. Pos. 2-4,8,39,72	Housing complete incl. pos. 2-4,8,39,72
2	2973. 100. 094	Lager	Bearing
3	2973. 100. 095	Lager	Bearing
4	1933. 710. 100	Nadellager	Bearing
6	2973. 100. 096	Griffplatte	Handle plate
7	1911. 704. 089	Senkschraube	Counter sunk screw
8	1821. 027. 015	Linsensenkschraube	Oval head screw
11	2973. 100. 211	Messer komplett inkl. Pos. 12-17	Knife complete incl. pos. 12-17
12	2973. 100. 101	Bügel	Bow
13	2973. 100. 102	Messer	Knife
14	2973. 100. 103	Gegenmesser	Counter knife
15	2973. 100. 104	Achse	Shaft
16	2973. 100. 105	Feder	Spring
17	1920. 204. 042	Aussen-Sicherungsring	Retaining ring
20	1910. 803. 069	Zylinderschraube	Cylinder screw
23	2973. 100. 180	Anschlag	Stop pin
24	2970. 000. 010	Tellerfeder	Saucer spring
28	2973. 100. 214	Stempel komplett inkl. Pos. 30-35	Punch complete incl. pos. 30-35
30	2973. 100. 139	Halteschraube	Screw
31	1921. 303. 121	Zylinderstift	Cylindric pin
32	2973. 100. 023	Hülsenanschlag vorn	Seal stop front
33	2973. 100. 025	Hülsen-Niederhalter	Seal retainer
34	2973. 100. 026	Druckfeder	Spring
35	1910. 405. 052	Gewindestift	Set screw
36	1821. 027. 027	Senkschraube	Counter sunk screw
37	2973. 100. 107	Stempelhalter-Platte	Punch holding plate
39	1821. 027. 016	Linsensenkschraube	Oval head screw
40	2973. 100. 108	Hülsen-Anschlag hinten	Seal stop pin rear
41	2973. 100. 142	Segmentrad-Exzenter	Excentric segment wheel
42	2973. 100. 109	Rückzugplatte	Back-up plate
43	2973. 100. 110	Druckrolle	Pressure roller
44	2973. 100. 181	Scheibe hinten	Washer back
45	1920. 110. 122	Sicherungsscheibe	Lock washer
48	2973. 100. 222	Klinke komplett inkl. Pos. 50-54,85	Clamp pawl complete incl. pos. 50-54,85

Pos.	Artikel-Nr. Part no	Benennung	Part name
50	2973. 100. 265	Klinkenarm	Clamp arm
52	1821. 046. 006	Klinkenfuss	Clamp plate
53	2973. 100. 033	Schaftschraube	Bolt screw
56	2973. 100. 215	Wippe komplett	Rocker complete
62	1821. 012. 009	Feder	Spring
63	1921. 604. 201	Spiralstift	Roll pin
71	1921. 305. 201	Zylinderstift	Cylindric pin
72	1910. 006. 108	Gewindestift	Set screw
73	2973. 100. 268	Hebel komplett Orga-Blau	Lever complete Orga-blue
76	2973. 100. 121	Betätigungsstift	Activating pin
77	2973. 100. 122	Lager hinten	Bushing back
78	2973. 100. 123	Lager vorne	Bushing front
79	2973. 100. 124	Bügel	Bow
80	2973. 100. 048	Feder vorne	Spring front
81	2973. 100. 049	Stossstange	Thrust rod
82	2973. 100. 050	Feder	Spring
84	2973. 100. 052	Arretierstift	Lock pin
85	2973. 100. 053	Druckfeder	Spring
86	1921. 304. 121	Zylinderstift	Cylindric pin
87	1910. 804. 040	Zylinderschraube	Cylinder screw
88	2973. 100. 253	Arretierung	Lock plate
89	2973. 100. 125	Klinke (Anzugswelle)	Ratchet (windlass)
90	2973. 100. 126	Feder	Spring
92	2973. 100. 128	Schaftschraube	Bolt screw
93	2973. 100. 175	Druckstange	Push rod
95	2973. 100. 129	Ritzel	Gear
96	2973. 100. 130	Klinkenrad (Stempel)	Ratchet wheel (punch)
97	2973. 100. 131	Klinkenrad (Anzugswelle)	Ratchet wheel (windlass)
98	2973. 100. 132	Anzugswelle	Windlass
100	2973. 100. 260	Klinke (Stempel)	Ratchet (punch)
101	2973. 100. 133	Rückplatte komplett inkl. Pos. 102,103	Rear plate complete inkl. Pos. 102,103
102	2973. 100. 134	Lager	Bearing
103	2973. 100. 135	Lager	Bearing
104	2973. 100. 136	Feder zu Exzenter	Spring for excentric

Pos.	Artikel-Nr. Part no	Benennung	Part name
105	1912. 504. 068	Flachkopfschraube	Head screw
106	2973. 100. 138	Griff	Handle
107	1920. 212. 102	Aussen-Sicherungsring	Retaining ring
108	1821. 027. 017	Linsensenkschraube	Oval head screw
109	2973. 100. 288	Federpaket komplett	Spring package complete
110	2973. 100. 262	Schulterbolzen	Shoulder bolt
111	2973. 100. 258	Klinke	Pawl
114	2973. 100. 057	Druckfeder	Spring
115	2973. 100. 261	Gewindebolzen	Threaded bolt

